


Cap heat press machine



We recommend (165-175seconds) for 15-25seconds (preheat for 15seconds)

1. Open power switch, setting time, temperature. Press "set". display shows "sh" to set temperature. Usually 180*c-200*c "set" again, show "st" to set time, usually 15s-25s.
2. Waiting for the heat plate to get to the set temperature (heating to 180*c needs about 3-5 minutes to heat up).
3. put the cap into the heat press Preheat the cap for (15seconds at 180*c)
4. then put your transfer onto the cap then close the handle, when the handle is closed it will set off the micro switch it will start to count down and when it beeps you lift the handle back up.
5. (Imbedding the design onto the cap) put the cap onto the heat press and pull down the handle for (5seconds at 180*C) then lift the handle take out your cap.

Technical parameter:

- Specified voltage: **220v**
- Power: **350kw**
- Temperature range: **0-399*c**
- Time range: **0.999secs**
- Dimension: **60x45x34cm**
- Net weight: **16kg**
- Gross weight: **18kg**